



SIMPLICITY BIG LOADS HARD GROUND POLYVALENCE

SPEED MONOLITHIC ENVIRONMENTAL FRIENDLY CHALLENGING LOGISTICS












ABOUT CONCRETE CAISSONS AND FLOATING DOCKS





SOURCE: Guía de Buenas Prácticas para la Ejecución de Obras Marítimas (Puertos del Estado)

ABOUT CONCRETE CAISSONS AND FLOATING DOCKS





IDEAL CONDITIONS FOR CAISSONS:

Hard ground conditions

- High loads transmitted to the ground
- Reduction of geotechnical risk


Sustainability

- No noises, no vibrations
- Off-site fabrication
- Lower materials consumption
- Smaller footprint

Challenging logistics

- Large water depths
- High loads

ABOUT CONCRETE CAISSONS AND FLOATING DOCKS





IDEAL CONDITIONS FOR CAISSONS:

Hard ground conditions

- High loads transmitted to the ground
- Reduction of geotechnical risk


Sustainability

- No noises, no vibrations
- Off-site fabrication
- Lower materials consumption
- Smaller footprint

Challenging logistics

- Large water depths
- High loads

ABOUT CONCRETE CAISSONS AND FLOATING DOCKS





IDEAL CONDITIONS FOR CAISSONS:

Hard ground conditions

- High loads transmitted to the ground
- Reduction of geotechnical risk

Sustainability

- No noises, no vibrations
- Off-site fabrication
- Lower materials consumption
- Smaller footprint

Challenging logistics

- Large water depths
- High loads

ABOUT CONCRETE CAISSONS AND FLOATING DOCKS





IDEAL CONDITIONS FOR CAISSONS:

Hard ground conditions

- High loads transmitted to the ground
- Reduction of geotechnical risk

Sustainability

- No noises, no vibrations
- Off-site fabrication
- Lower materials consumption
- Smaller footprint

Challenging logistics

- Large water depths
- High loads

ABOUT CONCRETE CAISSONS AND FLOATING DOCKS



Example of challenging logistics: Port of Açu (Brasil)








ABOUT CONCRETE CAISSONS AND FLOATING DOCKS



Caissons used for breakwaters

Caissons used for quays

Breakwater + quay






Caissons used for breakwaters

Caissons used for quays

Breakwater + quay
















- Two structures vs. one
- Equipment mobilization
- Wider occupation
- Longer schedule













- Two structures vs. one
- Equipment mobilization
- Wider occupation
- Longer schedule


























ABOUT CONCRETE CAISSONS AND FLOATING DOCKS




Caissons used for breakwaters

Caissons used for quays

Breakwater + quay







ABOUT CONCRETE CAISSONS AND FLOATING DOCKS



Caissons used for breakwaters



For large water depths:

- Faster construction
- Lower materials consumption
- Smaller footprint









ABOUT CONCRETE CAISSONS AND FLOATING DOCKS









30m water depth Hs = 9,50m











Caissons used for breakwaters Caissons used for quays Breakwater + quay






acciona








ABOUT CONCRETE CAISSONS AND FLOATING DOCKS



Caissons used for breakwaters

Caissons used for quays

Breakwater + quay










FLOATING DOCK



DRY DOCK



SPECIAL FACILITIES









FLOATING DOCK













FLOATING DOCK











ABOUT CONCRETE CAISSONS AND FLOATING DOCKS









- Onshore surface required
- Enough bearing capacity or time for ground improvement
- Launching device required
- Several production lines
- Typically used for large number of caissons







- Onshore surface required
 - Enough bearing capacity or time for ground improvement
- Launching device required
- Several production lines
- Typically used for large number of caissons









- Onshore surface require
- Enough bearing capacity or time for ground improvement
- Launching device required
- Several production lines
- Typically used for large number of caissons





- Fast set up and earlier starting
- Low requirements at the port
- Floating dock required
- Early contact with sea water











- Fast set up and earlier starting
- Low requirements at the port
- Floating dock required
- Early contact with sea water

ABOUT CONCRETE CAISSONS AND FLOATING DOCKS











- Fast set up and earlier starting
- Low requirements at the port
- Floating dock required
- Early contact with sea water

ABOUT CONCRETE CAISSONS AND FLOATING DOCKS









- Fast set up and earlier starting
- Low requirements at the port
- Floating dock required
- Early contact with sea water









- Able to fabricate caissons 67m longn and 34m height
- Patented system based on 15 jacks on each side that pull the formwork upwards
- Onshore concrete supply for a 24/7 fabrication
- Fabrication rate 4-5m/day (height)


ABOUT CONCRETE CAISSONS AND FLOATING DOCKS


























ABOUT CONCRETE CAISSONS AND FLOATING DOCKS



